

Beacon B200 quick start

Connect Beacon to a stable 5 V USB power supply.

Choose a 2.4 GHz Wi-Fi network for pairing.

Hold the reset button for 12 seconds to clear saved credentials.

The amber light flashes when reset is complete.

A reset retains installed firmware.

Pairing and escalation

For error E17, check the Wi-Fi password and MAC filtering.

Repeat pairing within 3 metres of the router.

After a failed reset, contact support with the device serial number, firmware version, and router model.

Never send your Wi-Fi password to support.